



**"SONOR SOUND MACHINE"
XK 9212 KS**

- G 322 2 Bass Drums 22" x 14"
- D 566 Snare Drum 14" x 6 1/2"
- T 706 Concert Tom Tom 6" x 5 1/2"
- T 708 Concert Tom Tom 8" x 5 1/2"
- T 710 Concert Tom Tom 10" x 6 1/2"
- T 712 Concert Tom Tom 12" x 8"
- T 713 Concert Tom Tom 13" x 9"
- T 714 Concert Tom Tom 14" x 10"
- T 715 Concert Tom Tom 15" x 12"
- T 716 Concert Tom Tom 16" x 14"

- T 738 Floor Tom Tom 18" x 16"
- Z 5317 2 Bass Drum Pedals
- Z 5554 Snare Drum Stand
- Z 5226 4 Tom Tom Stands
- Z 5457 Hi Hat (fitted with special Bass Drum attachment)

- Z 5224 2 Cymbal Stands
- Z 5227 2 adjustable Boom Arms for Cymbal Stands


ALL drums fitted with
REMO CS Weather King Heads.




SONOR




SONOR-PHONIC




KK Metallic copper



KB Metallic blue



CW High gloss white



AG Acrylic clear



PA Natural rosewood



SONOR-PHONIC outfit
XK 925 KK


- G 322 Bass Drum 22" x 14"
- D 565 Snare Drum 14" x 5 3/4"
- T 723 Tom Tom 13" x 9"
- T 724 Tom Tom 14" x 10"
- Z 5503 b Double Tom Tom Holder
- T 736 Floor Tom Tom 16" x 16"
- Z 5317 Bass Drum Pedal
- Z 5554 Snare Drum Stand
- Z 5454 Hi Hat Stand
- Z 5224 2 Cymbal Stands

ALL drums fitted with
REMO Weather King Heads.



SONOR Tom Tom Holders are fitted with a steel covered, spring loaded, wedge-type, locking mechanism, housed in a metal casing to ensure complete stability of Tom Toms when locked in position.

SONOR Floor Tom Toms are fitted with legs and leg boxes as standard. The leg boxes feature a prism locking mechanism (DGM) for absolute security and reliability.





9 ply full vibrating sound shells, floating heads, and special (45°) angled rims, optimum overall spring-loaded tension brackets, make SONOR-PHONIC percussion instruments the most advanced in the world.

Two dimensional Bass Drum spurs with prism locking mechanism (DGM), adjustable rubber pads and chromed steel tips for absolute security and reliability.




SONOR-PHONIC outfit


XK 946 AS

- G 324 Bass Drum 24" x 14"
- D 566 Snare Drum 14" x 6 1/2"
- T 724 Tom Tom 14" x 10"
- T 725 Tom Tom 15" x 12"
- Z 5503 b Double Tom Tom Holder
- T 736 16" x 16" Floor Tom Tom
- T 738 18" x 16" Floor Tom Tom
- Z 5317 Bass Drum Pedal
- Z 5554 Snare Drum Stand
- Z 5454 Hi Hat Stand
- Z 5224 2 Cymbal Stands

ALL drums fitted with
REMO Weather King Heads.



KS Metallic silver




KO Metallic orange



CB High gloss black







AS Acrylic smoky



AB Acrylic blue

- Z 5454 Hi Hat Stand
- Z 5457 Hi Hat (fitted with special Bass Drum attachment)
- Z 5554 Snare Drum Stand
- Z 5529 Snare Drum Stand extension tube (for added height)
- Z 5226 Tom Tom Stand





Z 5227


- Z 6204 Stand for Bongos or Timbales
- Z 5224 Cymbal Stand (extra-wide base)
- Z 5227 Adjustable Boom Arm for Cymbal Stand
- Z 5228 Double Cymbal Stand

Z 6204

Z 5224

Z 5228

 **SONOR**



Z 5322

Z 5317 SONOR-PHONIC[®] Bass Drum Pedal
 Two heavy-duty chrome plated support pillars carry a specially designed cross member mounted on long life roller bearings with an adjustable throw/beater mechanism. Three separate springs, hard, medium and soft, are supplied free with each pedal. The finely modelled foot plate is inset with non-slip rubber and there is an extra large easy-grip locking screw fitted allowing swift clamping of the pedal to the Bass Drum.

Z 5321 "Super-Champion" Bass Drum Pedal
 This single post eccentric action pedal is multi-adjustable, from the length of the action and throw, to the height and length of the beater. Adjustments can be made by using the standard "SONOR" drum key supplied with each pedal. Three separate springs, hard, medium and soft, are also supplied.

Z 5322 "Super-Champion" Bass Drum Pedal
 Specification as Z 5321 except for the following: Single piece foot-plate, adjustable in length and fitted with toe stop.